

Lakeland ChemMax® Push Fit Glove System

Quickly Install Or Remove Chemical Gloves On Lakeland ChemMax® or Interceptor® Suits!

The Lakeland ChemMax® “Push-Fit” Glove System is a simple method of attaching most types of chemical gloves to the garment sleeve through the use of two concentric rings. The system has been fully tested to a CE Type 3 Jet Test and is certified for use with all Lakeland ChemMax® and Interceptor® chemical protective coveralls. Lakeland’s “Push-Fit” Glove System is reusable and may need decontamination before reuse.

Lakeland item number JFR2 contains one set of “Push-Fit” rings, and will secure one pair of gloves to any Lakeland chemical protective coverall.



Push Fit Glove System Installation Instructions



1 Pull the cuff of the glove over the white ring - insert the narrower end of the ring first.



2 Pull the cuff over the full length of the ring



3 Push the glove with ring into the garment sleeve.



4 Ensure the correct glove is used for each sleeve and that the palm of the glove faces the front of the garment.



5 Holding the sleeve behind the inner ring slide the black ring over the glove and on to the garment sleeve.



6 Push tightly over the inner ring and ensure the sleeve hem remains hooked over the lip of the inner ring.



7 Ensure both rings are attached securely and correctly to each sleeve

WATCH OUR VIDEO!



See how quick and simple the installation process is. Watch the instructional video by scanning the QR Code or visiting www.lakeland.com/blog/cat/technicalvideos

Lakeland Push Fit Glove System – Part No. JFR2



800-645-9291 | Tel: 256-350-3873 | info@lakeland.com | lakeland.com